


IA / IAX Cable BTSpac Installation Pages: 2 - 3

IA/IAX CABLE BTSPAC INSTALLATION

1



IA/IAX CABLE BTSPAC INSTALLATION



Step 1: Remove the rear wheel to simplify the installation.





Step 3: Slide the box up over the top screw post. Insert the top screw and tighten to 4Nm.



Tighten to 4Nm.




Step 2: Install the lower screw. Turn 3 or 4 revolutions.

Step 4: Tighten the lower screw by inserting a ball-end Hex wrench through the hole on the bottom of the box.



IA/IAX CABLE BTSPAC INSTALLATION (CONTINUED)



Step 5: Insert the supplied plug in the hole to seal it.





Step 6: Reinstall the rear wheel.