



**FEELT**

Compulsion Suspension Manual

## Contents:

1. Introduction
2. Equilink Function Simply Explained
3. Setup
4. Rebuild / Maintenance
5. Parts Lists

### 1. Introduction To The Equilink:

Congratulations on purchasing this high quality Felt Equilink equipped bicycle. As with all of our bikes and components, our aim is to provide you, the rider, with the best possible product and therefore the best possible riding experience.


Please read this Equilink Owners manual supplement thoroughly, as its purpose is to help you better understand your bike, set it up correctly, and care for it. If there are any questions that you still have after reading this guide, please contact your Felt Equilink Authorized Dealer, or visit our comprehensive Equilink website at [www.Feltbicycles.com](http://www.Feltbicycles.com).

Happy Trails!  
Felt Bicycles.

### 2. The Equilink Function Simply Explained:

In this illustration notice the red **Equilink** located behind the seat tube. The positioning of this special link counteracts weight transfer, so that the drivetrain doesn't have to.

As you pedal, the **Equilink** automatically pulls down on the upper horizontal link, which instantly negates and equalizes weight transfer. The harder you pedal the more weight transfer you initiate. The Equilink simply mirrors the effort, keeping a constant state of equalization. By allowing the drivetrain to do what it was meant to do (move you forward), we are able to maximize pedaling efficiency while allowing the suspension to remain equalized, and stay ultra-compliant as it moves freely over even the smallest of bumps.



### 3. Equilink Suspension Setup Guide:

Each Felt Suspension bike has a recommended shock absorber sag setting range that corresponds with the type of riding that model was designed for. This suggested setting can usually be found as a laser-etched mark or decal on either the left or right upper link plate close the top end of the shock absorber.

To determine your actual sag you must first slide the travel indicator on the shock absorber (the small "o"-ring on the effective shaft of the shock) upwards until it rests against the larger part of the shock. Be sure to turn off the "Pro Pedal" on bikes equipped with an RP23 shock. Then, with both hands on the respective handlebar grips throw a leg over the bike and gently allow your full body weight to compress the suspension. Then, slowly roll off lifting your weight off the bike. When you now look at the shock you will see that the o-ring has moved. The distance between the o-ring and the top body of the shock is the actual shock sag dimension.

**Important:** Try not to "bounce" or sit up while applying weight to the bike. Doing so can drastically throw off the resulting measurement. If you feel you have made an error, you can easily slide the travel indicator up and start over.

Suggested sag settings should only be used as an initial starting point. In many cases the actual settings that work best for you may be different than what works for others due to riding style, terrain or simply personal preference. Since the performance of the suspension is not dictated by certain shock settings or specific ride height, we suggest that you experiment with air pressure and damping settings to arrive at "your" desired feel. More sag (less air pressure) for a softer, suppler ride or less sag (more air pressure) for a firmer ride.

**WARNING:** The bicycle should be considered as a system when setting air pressures. Changing rear shock air pressure will effectively change the bikes geometry, so the fork air pressure/preload should be checked at the same time for correct sag to ensure proper geometry and handling. Failure to do so could adversely affect steering and handling characteristics, resulting in possible loss of control, injury, or even death. Refer to the fork owner's manual for instructions on setting correct sag, air pressure and damping settings. If you did not receive or misplaced your fork owner's manual, refer to the manufacturer's website for details on proper care and maintenance procedures.

## 4. Equilink Maintenance Overview:

Unless you're a sponsored pro, or fortunate enough to have your own personal mechanic, you're going to be the one looking after your bike. While all Felt frames are designed to be strong and durable, a little preventive maintenance will protect your investment and provide endless hours of trail riding fun.

### General Maintenance

All bearings used on Felt suspension frames are high quality sealed units. They are designed to provide a long working life; however keeping the bearings clean will extend their useful life.

When cleaning your bike, avoid the use of high pressure water or aerosol spray cleaners. Doing so will drive contaminants into the bearings, causing premature failure. The easiest and simplest way of cleaning the frame is using a bucket of soap and water. This will remove all exterior dirt and grime, preserving the integrity of the bearing seals.

When cleaning the frame it is good practice to periodically check for bearing wear.

1. With the bike in a workstand, clamped by the seatpost, remove the rear wheel and deflate the rear shock.
2. Standing behind the frame, lift the rear dropouts, (Move suspension as shown in Fig.1) it should feel smooth, (with light resistance from the carbon rear triangle on so equipped bikes). Any grinding, notchiness or tight spots may be signs that the bearings need to be overhauled.




Fig.1




Fig.2

3. If the suspension moves smoothly through its travel, check for any side to side movement. Hold the dropouts and try and move them to the left and right. Any looseness may be a sign of loose bearing bolts or worn bearings. (Move suspension as shown in Fig.2)
4. Check the bearing bolts, if any are loose tighten them to the torque spec that is conveniently laser etched into the dust shields. In some instances it may be necessary to reapply a thread locker before you retighten the bearing bolts.
5. If you notice any wear or problems with the bearings your easiest course of action is to replace them. Bearing replacement kits are reasonably inexpensive (remember we use commonly sized bearings for that very reason) and the procedure is fairly simple. Bearing kits and complete rebuild kits are available through your local Felt Bicycles retailer.
6. For rear shock maintenance refer to the shock manufacturers owners manual that was included with your bike. If you did not receive or misplaced your shock owner's manual, refer to the manufacturer's website for details on proper care and maintenance procedures.

## Bearing Replacement:

**IMPORTANT** - Read and thoroughly comprehend these instructions prior to beginning. Doing so will save you time in the long run and help keep your Felt frame running smoothly and safely.

Tools required:


Loctite 680 (Retainer Compound)  
Loctite 242 (Thread Locker)  
4mm, 5mm and 6mm Allen (hex) wrench  
Torque wrench (Metric) with 5 and 6mm hex bit  
12mm and 15mm open wrench  
Equilink Bearing removal/installation tool kit  
Rubber/plastic faced hammer  
X-acto knife or dental pick  
Cleaner/degreaser  
Acetone or similar solvent  
Q-Tip or similar

## Frame Disassembly:

1. **CLEAN YOUR BIKE!!** Even if you clean your bike regularly, clean it again. Dirt and contaminants including oil and grease will affect the reassembly of the frame components and could prevent bearings from seating correctly and could also keep the Loctite from curing.
2. After clamping the bike in a work stand, remove the wheels, rear derailleur, rear brake caliper, crank set and BB. The fewer components on the frame the easier it will be for you to work on!
3. Break loose each pivot bolt, but do not remove any hardware yet.
4. Deflate the shock, remove the shock mounting bolts and set the shock to the side.
5. Remove the Equilink mounting bolts and axles, and remove the Equilink from the upper and lower links. Set the Equilink to one side with the shock.
6. Remove the upper and lower bearing bolt/dust shield assemblies that attach the rear triangle to the linkage. Remove the rear triangle along with the stainless steel spacer washers that are in between the bearings and the linkage components.
7. Now remove the bearing bolt/dust shield assembly from the lower link. The lower link should be free from the frame. Be careful to not lose any stainless steel spacer washers.
8. Remove the bearing bolt/dust shield assembly from the shock links. Be careful to catch the link spacer (item #6 in Fig. 11) at the back of the link and the stainless steel spacer washers. The shock link plates should now be free from the frame.

## Master Bearing Tool Kit Diagram:

**Note:** Not all tools from the master tool kit will be needed for this model of Felt Bicycle and may not be included in your bike's tool kit.



## Removing Bearings:

1. Place the links flat on your bench and assemble the bearing removal tools as shown in fig. 3. Use an Allen wrench and open wrench to draw the bearings out of the links. Repeat this process for the lower link bearings, chain stay yoke bearings and seat stay bearings (Use tool "B" in place of tool "A" for the smaller Seat Stay Yoke bearings) as needed.




Fig.3

2. Disassemble The dropout Pivots as follows:

- A Remove the chainstays from the seatstays by removing the clevis bolts/nuts at each dropout.
- B Orient the tools as seen in Fig. 4. Use the special M6 bolt, with 8mm head, included in the tool kit.
- C Tighten the bolt against the spacer that fits between the bearings in the dropouts to press the first bearing out.




Fig.4

3. To remove the Equilink Needle Bearings you must first remove the Grease Needle Fittings. This can be done by gently pulling them out with a set of good quality pliers. Discard the fittings you just removed. There is a new set of grease fittings included with your rebuild kit. After the grease fittings are removed, orient the tools as shown in Fig. 5. Tighten the bolt until both bearings inside each (top and bottom) barrel of the Equilink are pressed into the bearing receiver (N).




Fig.5

## Installing Bearings:

1. Once all the bearings have been removed, clean the bearing bores using the dental pick or X-acto knife to remove all traces of old bearing seating compound/green loctite. Wipe down the bearing bore with a Q-tip soaked in a small amount of solvent such as acetone. This will remove any last traces of loctite and other contaminants. Don't get solvent on any other portion of the frame or rear triangle as damage to the paint or carbon resin may occur.

**IMPORTANT** - The properties that make Acetone and similar solvents work so well as a cleaner can also harm paint and break down carbon fiber resin. Be very careful where you apply the solvent as it may compromise the integrity of the rear triangle and/or the paint finish of your frame.

(Caution-Eye and Hand protection should **ALWAYS** be used when handling solvents to avoid contact!)

2. Once you've cleaned the bearing bores, apply a small amount of grease to the inside surface of the bearing bore and the outside of the bearing. Assemble the bearing installation tool (as shown in Fig.6). Using the Allen wrench and open wrench to press (or draw) the bearing into place. Make sure the bearing is seated completely and cleanly into the link. Repeat this process for the Seat Stay Yoke bearings (Use tool "B" in place of tool "A" for the smaller Seat Stay Yoke bearings) as needed.




Fig.6

3. To reassemble the lower link you will use the link support included in the Equilink tool kit. Install the bearings one at a time as shown in Fig. 7.




Fig.7

4. To assemble the dropout pivots the first bearing install is the same as described in bearing installation step #2.  
To install the second bearing:
  1. Orient the tools as seen in Fig. 8.
  2. Tighten the nut and bolt together until they are tight around the bearing tools. The washer should fit flat against the dropout. The 19mm bearing tool should have the press side touching the bearing to press it in.
  3. Hold the nut with an open wrench and turn the bolt with an Allen key. The 19mm bearing tool should push the bearing smoothly into the link. Do not forget the small spacer that fits between the 2 bearings (pictured below, also item #25 in Fig. 9).




Fig.8

5. To press fresh Needle Bearings into the Equilink, orient the tools as seen in Fig. 9. Tighten the bolt until the Flange on the EQ Bearing Press (K) touches the Equilink. The tool is designed to set the Bearings to the correct depth inside the Equilink. Repeat for all 4 Equilink Needle Bearings.




Fig.9

6. After making sure that the bearing bolt/dust shield assemblies are cleaned of any contaminants, discard any damaged bearing bolts. You are now ready to re-assemble the frame.

## Frame Reassembly:

(Note: use Loctite 242 on all threads when reassembling)

1. Take the rebuilt lower link along with the stainless steel spacer washers (placed on the inside between the bearing and the frame) and slide the link into place (some force may be required). Then reinstall the bearing bolt/dust shield assembly, tightening it to the torque specified on the dust shields.
2. Attach the rebuilt upper link plates to the frame, making sure the stainless steel spacer washers are in place (placed on the inside between the bearing and the frame) and the link spacer is in place. Again torque the bearing bolt/dust shield assembly to the torque specified on the dust shields.
3. Install the Equilink. The link is not symmetrical so it can't be installed in the wrong direction. Slide the ends of the link, along with the press in polymer washers, into the lower link and then between the shock links. Install the fixing bolts. Be sure to apply a small amount of 680 Loctite to the shoulder of the Equilink bolt (see fig. 10) Tighten to the torque indicated on the links.




Fig.10

4. Attach the chain stays to the lower link. With the stainless steel spacer washers in place tighten the bearing bolt/dust shield assemblies to the torque indicated on the dust shields.
5. Attach the seat stays to the upper link. The links may need to be rotated up and down to position the link bolt holes in the correct position. Again, with the stainless steel spacer washers in place tighten the bearing bolt/dust shield assemblies to the torque indicated on the dust shields.
6. Reconnect the dropout pivots. Insert the reducer spacers (item #21 in Fig. 11) into the bearings in the dropouts and slide the seat stay clevises over the bearings and spacers. Insert the bolt, with washer, from the outside of the frame through the bearings and into the clevis nut that presses into the inside (wheel side) of the clevis.
7. Re-install the shock, remembering that the upper and lower bolts are different lengths. Once the bolts are assembled in their proper locations they will need to be tightened to the torque specified on the shock link.

8. Once complete, re-inflate the shock to your preferred pressure and/or recommended sag (see Section 3 of this manual for proper sag settings).
9. Pack the barrel of the Equilink with grease using a needle nose grease gun. The grease fittings on the back of the Equilink allow a quick and easy service interface for the user to maintain the pivots of the Equilink.
10. Reinstall any parts you removed initially to access your suspension components.
11. Go Ride...
12. All pivot and mounting bolts should be re-checked for correct tightness/torque after the first ride and periodically ever few rides after that.






Fig. 11

## Compulsion Series Parts List:

	QTY / Bike	
1.	Compulsion Alloy Seatstay Assembly	1
2.	Chainstay Link	1
3.	Compulsion Equilink	1
4.	Compulsion Shock Link (Left)	1
5.	Compulsion Shock Link (Right)	1
6.	Shock Link (Left)	1
7.	Pivot Nut Assembly (66.0mm lg.) w/22mm Cap	1
8.	Pivot Nut Assembly (78.0mm lg.) w/22mm Cap	2
9.	Pivot Nut Assembly w/22mm Cap	3
10.	Bearing Spacer 2.5mm	8
11.	Bearing 22x8x7 608 2RS Max Fill	6
12.	Bearing 19x8x6 698 2RS Max Fill	6
13.	Needle Bearing (INA) #HK08 1ORS	4
14.	Polymer Thrust Washer	4
15.	Bolt M6 x 1.0 x 35.0mm Long, Plated	1
16.	Bolt M6 x 1.0 x 40.0mm Long, Plated	1
17.	Upper Equilink Bolt 55.5mm Long	1
18.	Lower Equilink Bolt 43mm Long	1
19.	Grease Port Filling, Allemite #1877	2
20.	Pivot Bolt Assembly (78. mm lg.) w/19	1
21.	Pivot Nut Assembly w/19mm Cap	1
22.	Compulsion Alloy Chainstay Assembly	1
23.	M8 to M6 Reducer Bearing Spacer	4
24.	M6 Flat Washer	2
25.	M8 to M6 Reducer Clevis Nut	2
26.	M6 X 1.0mm SHCS X 20.0mm LG., Plated	2
27.	M8 to M6 Reducer Bearing Spacer 2 Sided	2



Detail A Drop-out Pivot    Detail B Shock Link To S/S Pivot    Detail C Lower Link To F/T Pivot    Detail D Shock Link To F/T Pivot  
Chainstay To Lower Link

Please visit [feltbicycles.com](http://feltbicycles.com) for the latest technical information on our proprietary technology.



Felt Bicycles 12 Chrysler Irvine, California 92618, USA

[feltbicycles.com](http://feltbicycles.com)